This user guide is for devices with the software version 1.0.0 or newer.

MOUNTING

The device can be installed in dry surroundings (IP20) by screws on the wall surface or on the standard flush mounting box. The recommended installation height is 150…180 cm.

The device position should be selected carefully. All the error factors that can affect to the measurements should be eliminated as well as possible. The following list defines the typical measurement error factors.

- direct sun light
- occupant proximity
- air flow coming from windows or doors
- air flow coming from ventilation nozzles
- air flow coming from the flush mounting box
- differential temperature caused by external wall

Wiring

Device wiring and commissioning can only be carried out by qualified professionals. Always make the wirings while the power is switched off.



SELECTING THE MEASUREMENT INFORMATION TO BE VIEWED ON THE DISPLAY

The measurement values scroll on the N model display. The wanted value can be locked to view continuously by pressing the S1 button. You resume to the scrolling view by pressing the S1 button again.

NOTE: When the potentiometer (HD-PU) is configured to change the controller set point, the set point is shown on the display when the potentiometer is rotated.



A. S1 button

NOTE: In M models, the shown measurement information can be selected also via Modbus.

ML-SER TOOL

With the ML-SER tool you can change the device settings, controller and Modbus settings for example.

Connecting ML-SER tool to the device

1. Remove the display / HD-AL3 option.
2. Connect the ML-SER cable to the connector.



A. ML-SER cable

Measurement values are shown in turns on the ML-SER tool display.

ML-SER menu

ML-SER menu opens by pressing the M button. The values can be changed with the ”+” and ”-” buttons. The menu is device-specific and the content depends on the device and installed options.

The following menu structure contains the factory settings.



The diagram continues on the next page.



Modbus menu


COMMUNICATIONS
1 MODBUS ID
Modbus address [OFF / 1...247]
9.6 Baud rate (k)
Modbus speed [9.6 / 19.2 / 38.4]
n Parity
Parity bit [None / Even / Odd]

Modbus menu is available in M models. The bus settings can be changed through the menu.

Calibration menu



All the measurements can be tuned through the calibration menu.

- The temperature value can be adjusted by 0.1 °C steps.
- The humidity value can be adjusted by 1 % steps.

ML-SER tool display shows how much the current value is tuned.

Output menu



You can change the controller output (Y4) scale through the output menu.

Controller menu



The control output can be controlled either according to a one measurement value or according to the maximum selection of all values.

- The temperature values can be adjusted by 0.1 °C steps.
- The humidity values can be adjusted by 5 % steps.

In the maximum selection control, the control output signal is formed according to the measurement that causes the largest control signal value. The following situation is in the example figure:

- Humidity is 55 %
- Temperature is 21,5 °C



Potentiometer menu



Potentiometer menu is available if HD-PU option is installed. You can select the potentiometer output connector and disable the potentiometer through the menu. You can also set the potentiometer for the set point adjustment purposes. The potentiometer is connected to the Y4 output as factory setting.

- The temperature value can be adjusted by 0.1 °C steps.
- The humidity values can be adjusted by 1 % steps.

The set point that is adjusted with the potentiometer cannot be adjusted via Modbus.

NOTE: When the potentiometer is used for setting the internal controller's temperature set point (TE-SP), the potentiometer adjustment range is ±3 °C around the set point centre.

NOTE: You have to set the controller off, if the potentiometer is configured to Y4 output.

Relay menu



Relay menu is available if HD-R option is installed. The relay switching point and hysteresis can be changed through the menu.

The relay output can be controlled either according to a one measurement value or according to the all values.

- The temperature values can be adjusted by 0.1 °C steps.
- The humidity values can be adjusted by 1 % steps.

When the output is controlled according to the all values, the relay activates when one measured value exceeds the set point.

Info menu



You can check the device software version and reset the device to factory settings through the Info menu.

MODBUS

The parameter memory durability allows at least 1 million writing cycles.

Bus termination

The Modbus can be terminated by placing the MBUS TERM. jumper.



A. MBUS TERM. jumper

Modbus function codes

The device supports the following Modbus function codes.

0x01	Read Coils
0x02	Read Discrete Inputs
0x03	Read Holding Registers
0x04	Read Input Registers
0x05	Write Single Coil
0x06	Write Single Register
0x0F	Write Multiple Coils
0x10	Write Multiple Registers
0x17	Read/Write Multiple Registers

Modbus registers

NOTE: If you try to write a parameter value that is beyond the parameter value range, the value will be replaced by the nearest acceptable value. For example, if you write 270 to the register 40011, the value will be replaced by 260.

Coils

Register	Parameter description	Data type	Values	Range	Default
1	Y1 output overdrive activation	Bit	0 - 1	0: Off, 1: On	0
2	Y2 output overdrive activation	Bit	0 - 1	0: Off, 1: On	0
3	Y3 output overdrive activation	Bit	0 - 1	0: Off, 1: On	0
4	Y4 output overdrive activation	Bit	0 - 1	0: Off, 1: On	0
5	Relay overdrive activation	Bit	0 - 1	0: Off, 1: On	0
6	Relay overdrive	Bit	0 - 1	0: Off, 1: On	0
7	2-10 V controller output	Bit	0 - 1	0: Off, 1: On	0

Discrete inputs

Register	Parameter description	Data type	Values	Range
10001	Relay status	Bit	0 - 1	0: Off, 1: On

Input registers

Register	Parameter description	Data type	Values	Range
30001	Not in use	Signed 16	-	-
30002	Temperature measurement	Signed 16	0…500	0,0…50,0 °C
30003	Humidity measurement	Signed 16	0…100	0…100 %
30004	Y1 output voltage	Unsigned 16	0…1000	0,00…10,00 V
30005	Y2 output voltage	Unsigned 16	0…1000	0,00…10,00 V
30006	Y3 output voltage	Unsigned 16	0…1000	0,00…10,00 V
30007	Y4 output voltage	Unsigned 16	0…1000	0,00…10,00 V
30008	Active potentiometer value	Unsigned 16	0…1000	0,0…100,0 %
30009	Potentiometer set point value	Unsigned 16	variable	variable

Holding registers

Register	Parameter description	Data type	Values	Range	Default
40001	Y1 output overdrive	Signed 16	0…1000	0…10.00 V	0
40002	Y2 output overdrive	Signed 16	0…1000	0…10.00 V	0
40003	Y3 output overdrive	Signed 16	0…1000	0…10.00 V	0
40004	Y4 output overdrive	Signed 16	0…1000	0…10.00 V	0

Register	Parameter description	Data type	Values	Range	Default
4000**5**	Not in use	Signed 16	-	-	0
4000**6**	Temperature measurement tuning (offset)	Signed 16	-30…30	-3,0…3,0 °C	0
4000**7**	Humidity measurement tuning (offset)	Signed 16	-5…5	-5…5 %	0
4000**8**	Control method	Signed 16	0 - 1	0: P 1: PI	1
4000**9**	Controller output	Signed 16	0 - 1 - 2 - 3 - 4	0: OFF 1: not in use 2: temperature 3: humidity 4: maximum selection	3
400**10**	Not in use	Signed 16	-	-	700
400**11**	Set point, temperature	Signed 16	180…260	18.0…26.0 °C	210
400**12**	Set point, humidity	Signed 16	0…100	0…100 %	50
400**13**	Not in use	Signed 16	-	-	500
400**14**	Proportional band, temperature	Signed 16	10…320	1.0…32.0 °C	20
400**15**	Proportional band, humidity	Signed 16	10…100	10…100 %	50
400**16**	Integration time	Signed 16	50…5000	50…5000 s	300
400**17**	Active potentiometer usage	Signed 16	0 - 1 - 2 - 3 - 4 - 5	0: OFF 1: Y3 2: Y4 3: TE-SP 4: RH-SP 5: not in use	2
400**18**	Not in use	Signed 16	-	-	1100
400**19**	Not in use	Signed 16	-	-	5
400**20**	Not in use	Signed 16	-	-	750
400**21**	Not in use	Signed 16	-	-	1250
400**22**	Value shown on the display	Signed 16	0 - 1 - 2 - 3	0: not in use 1: temperature 2: humidity 3: scrolling	3
400**23**	Not in use	Signed 16	-	-	1
400**24**	Not in use	Signed 16	-	-	0
400**25**	Relay set point, temperature	Signed 16	0…500	0.0…50.0 °C	230
400**26**	Relay set point hysteresis, temperature	Signed 16	0…200	0.0…20.0 °C	20
400**27**	Relay set point, humidity	Signed 16	0…100	0…100 %	50
400**28**	Relay set point hysteresis, humidity	Signed 16	0…50	0…50 %	5
400**29**	Relay function	Signed 16	0 - 1 - 2 - 3 - 4	0: OFF 1: not in use 2: temperature 3: humidity 4: all	3
400**30**	Potentiometer temperature set point centre	Signed 16	100…300	10.0…30.0 °C	210
400**31**	Potentiometer humidity set point low limit	Signed 16	0…100	0…100 %	40
400**32**	Potentiometer humidity set point high limit	Signed 16	0…100	0…100 %	60
400**33**	Not in use	Signed 16	-	-	600
400**34**	Not in use	Signed 16	-	-	1200